

HALLS 5&6

VERSION 2 - 11/02/2020

Exhibition Upper Level

HALL 6

HALL 5

FOR CONTINUATION REFER TO HALL 6&7 LAYOUT



Indicates 500mm long bracing panels placed at 3 metre intervals

T

Indicates 1500mm building support column

Indicates 2.4 metre high wall

Indicates 1.2 metre high wall

Indicates 100" STAND NUMBER
Indicates 50" STAND SIZE m2
Indicates 2.4 metre high wall
Indicates 1.2 metre high wall
BOUNDARY MEASUREMENT IN METRES

LEGEND:



The BIA reserves the right to modify or change the floor plan entirely to meet the appropriate demand. Drawing is for reference only and is subject to change.